

# MODEL 115 Control Panel

## Single phase, simplex pump switch control.

The Model 115 control panel provides customers with a reliable means of controlling one 120, 208, or 240 VAC single phase pump in water and wastewater installations. A pump float switch turns the pump on and off. If an alarm condition occurs, an additional alarm switch activates the audio/visual alarm system. Common applications include pump chambers, sump pump basins, irrigation systems, and lift stations.

## PANEL COMPONENTS


- 1. Enclosure** measures 8 x 6 x 4 inches (20.32 X 15.24 X 10.16 cm). Choice of NEMA 1 (steel for indoor use), or NEMA 4X (ultraviolet stabilized thermoplastic with removable mounting feet for outdoor or indoor use).
- 2. HOA Switch** for manual pump control.
- 3. Green Pump Run Indicator Light**
- 4. Pump Circuit Terminal Block**
- 5. Alarm Circuit Terminal Block** (mounted on circuit board).
- 6. Alarm Fuse** (mounted on circuit board).
- 7. Alarm Power Indicator** (mounted on circuit board).
- 8. Ground Lug**

## STANDARD ALARM PACKAGE

- 9. Red Alarm Beacon** provides 360° visual check of alarm condition NEMA 1 style utilizes a door mounted indicator in lieu of a beacon.
- 10. Alarm Horn** provides audio warning of alarm condition (83 to 85 decibel rating) **Note:** NEMA 1 style utilizes an internally mounted buzzer in lieu of a horn.
- 11. Exterior Alarm Test/Normal/Silence Switch** allows horn and light to be tested and horn to be silenced in an alarm condition. Alarm automatically resets once alarm condition is cleared.
- 12. Horn Silence Relay** (mounted on circuit board).

**NOTE:** other options available.

**Note:**



**Model Shown 1151W600X**



## FEATURES

- Entire control system (panel and switches) is UL Listed to meet and/or exceed industry safety standards
- Dual safety certification for the United States and Canada
- Standard package includes float switches
- Complete, step-by-step installation instructions
- Five-year limited warranty

## OPTIONAL FEATURE

- **34" (86.36cm) Panel Mounting Post** (Factory Installed). Includes Simplex Installation Kit (Enclosure upsized to 10" x 8" x 6" (25.4 x 20.32 x 15.24 cm). Max. Enclosure size 14" x 12" x 6" (35.56 x 30.48 x 15.24 cm)

**SEE REVERSE SIDE FOR ORDERING INFORMATION.  
SEE PRICE BOOK FOR LIST PRICE.**



**SJE RHOMBUS**

PO Box 1708, Detroit Lakes, MN 56502

1-888-DIAL-SJE • 1-218-847-1317

1-218-847-4617 Fax

email: [customer.service@sjeinc.com](mailto:customer.service@sjeinc.com)

[www.sjerrhombus.com](http://www.sjerrhombus.com) **B.35**

115

# MODEL 115

### ALARM PACKAGE

- 0 = select options or no alarm package
- 1 = alarm package (includes test/normal/silence switch, fuse, red light, horn, & float)

### ENCLOSURE RATING

- I = Indoor, NEMA 1 (metal)
- W = Weatherproof, NEMA 4X (engineered thermoplastic)

### STARTING DEVICE

- 2 = SJE PumpMaster® Plus pump switch (0-15 FLA) ●
- 3 = 120 VAC Double Float® pump switch (0-15 FLA) ▲
- 4 = 240 VAC Double Float® pump switch (0-12 FLA) ▲
- 5 = Super Single® pump switch (120V = 0-15 FLA) (208/240V = 0-12 FLA) ▲
- 6 = No pump switch
- 7 = 120 VAC Double Float® Master pump switch (0-15 FLA) ●
- 8 = 240 VAC Double Float® Master pump switch (0-15 FLA) ●

### PUMP FULL LOAD AMPS

- 0 = 0-7 FLA
- 1 = 7-15 FLA

### PUMP DISCONNECTS

- 0 = no pump disconnect
- 4 = circuit breaker

### FLOAT SWITCH APPLICATION

- H or L = pump down or pump up (select 17 option)
- X = no floats

### OPTIONS *Listed below*

#### CODE DESCRIPTION

- 1A Red beacon only / no audio  
*(must select 1E if floats included)*
- 1C Horn only / no visual  
*(must select 1E if floats included)*
- 1E Alarm float
- 3A Alarm flasher
- 3B Manual alarm reset
- 6A Auxiliary alarm contact, form C
- 8A Elapsed time meter (120V)
- 8B Elapsed time meter (240V)
- 10E Lockable latch - NEMA 4X
- 10E Lockable latch - NEMA 1
- 10P Panel Mounting Post (Factory Installed. Includes Simplex Install. Kit)(Encl. upsized to 10x8x6.Max 14x12x6)

#### CODE DESCRIPTION

- 11C NEMA 1 alarm panel *(must select option 6A)*
- 11D NEMA 4X alarm panel *(must select option 6A)*
- 16A 10' cord in lieu of 20' *(per float)*  
*(Does not apply for Double Float® or Double Float® Master pump switches)*
- 16B 15' cord in lieu of 20' *(per float)*
- 16C 30' cord in lieu of 20' *(per float)*
- 16D 40' cord in lieu of 20' *(per float)*
- 17A SJE SignalMaster® / pipe clamp ● (alarm float only)
- 17E Sensor Float® Mini / pipe clamp ▲ (alarm float only)
- 17J Sensor Float® / pipe clamp ▲ (alarm float only)
- 19U HOA (Hand/Off Automatic) switch and pump run light through door mounted
- 19X Door mounted pump run indicator  
● Mechanically-activated    ▲ Mercury-activated